



# Technical Data

PRODUCT TECH

©2007 TORCO

## FFO FOAM FILTER OIL SPRAY

### >>Description

Torco FFO Foam Filter Oil Spray is formulated with special base oils and tackifier additives to prevent moisture and abrasive elements from passing through foam filter elements and entering the engine. FFO is easy to apply and will not dry out, drip, or run. FFO will not gum up or clog foam passages.

### >>Features

- >Synthetic blend formula
- >Prevents moisture and harmful elements from passing through the filter
- >Maximizes airflow for consist jetting and performance
- >Easy to apply and easy to clean up

### >>Application

Recommended for use on all foam filter elements found on a motorcycle, scooter, ATV, and many other 2-cycle and 4-cycle engine applications.

### >>Directions

Application: Shake well before use. Hold FFO 6-8 inches away from the filter surface and spray an even coat outside and inside the filter. Massage the filter to work in the product thoroughly. Do not ring out the filter, as damage may occur to the foam. To provide a good seal, apply a thin layer of Torco Multi-Purpose Waterproof Grease to the filter's sealing surface. Use latex or rubber gloves when applying filter oil.

Cleaning: Thoroughly wash the used filter with a light cleaning solvent or a combination of detergent and warm water until all dirt particles are removed from the foam. Rinse with clean water and squeeze out excess. Do not ring out the filter, as damage may occur to the foam. Once the filter is completely dry, apply FFO as directed above.

### >>Package Sizes / P/N

Description	FFO
13.0 Ounces	T850001RE
12/13.0-Ounce Case	T850001R

